

Mounting Instructions For Dock Ladder Quick Release Plates

"NOTE"

The Tapered Pin Nearest To The Edge Of The Dock Has a Slotted Hole to Allow For The Variation In The Spacing of Mounting Holes For Many Dock Ladders.

1. Attach Plates to Ladder With Cabled Pins To The Out Side And Slotted Hole As Shown.
2. Place Ladder, Where Required, and Mark The Location of The Plates On the Dock.
3. Remove Plates and Place Cabled Pins Back Into The Tapered Pins as Not To Lose Them While Bolting Plates to The Dock.
4. Align Plates With Marks Made on Dock And Locate Holes To Drill For Anchor Bolts (Not Included) To Bolt Quick Release Plates To Dock.

